


Firmware Update Software Installation

Precautions installation



- * Please download the latest PC software file from the Alpine website.
- The software can only be used under the Microsoft® Windows® operating system. Operating system: Windows 10, Windows 11.
- Before connecting the PXE-C80-88 or PXE-C60-60 machine to the computer, please install the ALPINE_OPTIM computer software correctly ([PXE-C80-88](#) / [PXE-C60-60](#)).
- After installing the ALPINE_OPTIM software, you can update the PXE-C80-88 or PXE-C60-60 machine firmware on the computer.

Firmware Update Introduction



- 1 Turn on the power of the product main unit.
- 2 Connect one end of the USB cable to the main unit's USB port and the other end to your PC.
- 3 Double-click the PXE-C80_C60 application icon on your PC to open the application.

- 4 Select [Firmware Update] from [Option] to open the firmware update.



- 5 Click [>] and select the main unit firmware update file
- 6 Click [Update] to update the main unit firmware.
The firmware update successfully ends when the update process reaches 100% and states "Firmware Update has Successfully Completed".
- 7 Click [OK] to finish updating the main unit firmware.
After it is updated, the device will restart automatically.

View About

Select [About] from the options page to enter the about page.
You can view the version number.

